

Updating Channels on the SB3 Media Player

Changing Channels on the Control Site:

Please use the following link to view instructions on how to change the channels on the control site:

<https://cs.business.stingray.com/doc/en/online-help/selecting-a-station/>

Changing Stations Directly on the SB3 LCD Screen:

1. On the front panel of the SB3, press any button to navigate to the **HOME** screen
2. Press the down button once to arrive to **TUNE STATION**
3. Press **SELECT**
4. For players with multiple zones, use the up and down arrows to navigate to the zone you would like to change
5. Press **SELECT**
6. Use the up and down arrows to navigate to the station you would like to play
7. Press **SELECT**

Station Scheduler:

Please use the following link to find more information on the station scheduler and how to schedule different stations throughout the day:

<https://cs.business.stingray.com/doc/en/online-help/station-schedulev2-stations/>